DOCUMENT MODIFICATION REQUEST (DMR) PAGE 1 of													
Print	or <b>Typ</b>	All Infor	mation (Ex	essing Instructions cept Signatures)	1	<sup>0</sup> ate 2/2/95	25 2/ <sub>6</sub> DMR No 95-D						
5-	21000		O 16/Rev	2		New Document Number or Document Number if it is to be changed with this Revision     N/A							
4 Originator's Name/Phone/Pager/Location N Elzinga/740-2740/WCFS Denver						Field Radiological Measurements							
	nent Type	X Proces	lure	7 Document Modification Type		_	_						
04		10.00-		☐ New ☐ Revision		<del></del>	Change LI Editorial Co	rrection					
8 item	9 Page	10 Step	11 Proposed Modifications										
1	9	6221	Between the present sentences four and five, add the following "For the OU-2 Trenches and Mound Site Characterization Program, a five point prework Fidler survey will be used to monitor each soil gas location within each IHSS. The first point will be the proposed soil gas location. The four additional points will each be five feet away from the soil gas location, one each to the north, south, east, and west."  ADMIN RECORD										
12. Justif	cation (Re	eson for Mod	fication EJO#	TP# etc.)									
within each IHSS The five point surveys will adequately identify surface soil radionuclide contamination in the IHSS  OU 2 Temporary Limited Scope Expires July 31, 1995													
				list concurring disciplines in Bloc igns in Block 14 and dates in Blo	ck 13, and enter N/A ock 15	in Blocks 14 and 15 W modific	cation is for any type of change or a						
13. Organ			(if applicable)			· · · · · · · · · · · · · · · · · · ·		15 Date (if applicable)					
SME		R U P T		okur DC	7.5			2-27-95					
QA	Mgi		<i></i>					11196					
				/ /									
					···· <u>······</u>								
			-		<del>,</del>								
				_									
16. Originator's Supervisor (print/algn/date) Peter J Laurin No Training Required													
17 Assigned SME/Phone/Pager/Location   18. Cost Center   19 Charge Number   20. Requested Completion Date   21 Effective Date   62 - 28 - 95													
22. Acosterated Review? 23.ORC Review NOT REQUIRED													
24 Respo	onelble Ma	neger (print, si Laurin	gn date)	162									
REVIEWED FOR CLASSIFICATION / UCNI BY													

DOCUMENT CLASSIFICATION REVIEW WAIVER PER CLASSIFICATION OFFICE

## FIELD RADIOLOGICAL MEASUREMENTS

			ATS PLANT ERATION SOP	Manual: Procedure No: Page: Effective Date:		5-21000-OPS FO.16, Rev. 2 1 of 16 02-28-95 Environmental Management	
Cate	gory 2			Organization.	Environmental		
		OLOGIO IENTS	CAL	Approved  JE EVU  (Name of Approver)	red [5]	/ /	
1 0 2 0 3 0 4 0	PURI RESF	POSE AN	CONTENTS ND SCOPE LITIES AND QUA S	LIFICATIONS		1 2 2 3	
	4 1 4 2		CE REFERENCES RNAL REFERENC			3 3	
5 0	EQU	PMENT	•			4	
	5 1 5 2	MONI SUPPI	TORING DEVICE LIES	S		4	
6 0	PROC	EDURE	S			5	
	6 1 6 2		K AREA CHARAC TORING TECHNI	CTERIZATIONS IQUES AND TASKS		5 5	
		6 2 1 6 2 2	Monitoring Technomorphisms Tasks	_	~	5 9	
7 0	DOC	U <b>MENT</b> .	ATION			16	
LIST	OF FIG	URES					
FIGURE FO 16-1 MINIMUM MAREA SURV				SUREMENT POINTS	FOR A PRE-WORK	10	
			LIST	OF EFFECTIVE PAC	GES		
	Page		E	ffective Date	Change Number		
	9			-1 <i>2</i> 8195	95-DMR-000103		
TOTA	AL NUN	IBER O	F PAGES 16 (with	nout forms)			

## FIELD RADIOLOGICAL MEASUREMENTS

EG&G ROCKY FLATS PLANT EMD MANUAL OPERATION SOP Manual: Procedure No.

5-21000-OPS FO.16, Rev. 2 9 of 16

Category 2

Effective Date: Organization:

Page:

**Environmental Management** 

Small area smear papers will be treated as low-level radioactively contaminated environmental materials

## 6.2.2 Monitoring Tasks

Radiological Engineering-approved subcontractor Health and Safety Specialists will monitor environmental materials containers, sample containers, equipment, and personnel exiting potentially contaminated work areas and work areas characterized as not potentially contaminated if monitoring by subcontractors indicates the potential presence of radiation contamination above background Radiological Engineering-approved subcontractor Health and Safety Specialists will also conduct prework area monitoring of potentially contaminated work sites. Prework area monitoring will be scheduled with a Radiological Engineering-approved subcontractor Health and Safety Specialist as far in advance as possible. A minimum notice of one workday is required.

## 6 2.2 1 Work Areas

Work area monitoring will be accomplished (prior to work starting) to indicate if surficial radioactivity exists in the immediate work area Prework area monitoring will be accomplished by making direct soil surface measurements with a Bicron Analyst Fidler (or equivalent instrument) A minimum of 17 measurement points will be used for a prework area survey A grid of the measurement points that is centered on the point of the intrusive activity is depicted in Figure FO 16-1 For the OU-2 Trenches and Mound Site Characterization Program, a five point prework Fidler survey will be used to monitor each soil gas location within each IHSS The first point will be the proposed soil gas location The four additional points will each be five feet away from the soil gas location, one each to the north, south, east, and west A measurement of 250 cpm or less as measured by a Bicron Analyst Fidler (or equivalent instrument) indicates only background levels of radioactivity are present At surface sediment sampling sites a single monitoring with a Bicron Analyst Fidler (or equivalent instrument) at the sampling point will constitute prework area monitoring Documentation of area monitoring will be accomplished by completing Section I of Form FO 16A, Results of Radiological Measurements In The Field

95-Ume-000103